How to change the ISDN PRI protocol in the 5ESS from Custom to NI-2:
Go to View 5.2u (Key field is PRI group number.)

- **Change:** Field 2 (STD=NI-2, Custom=5E custom)
  Note: PRI Grp is found in View 5.5, screen 2, field 56